



## OPHELIA LAMPS

*Designed by Christophe Pillet*

$\varnothing 26,7 \times H.120\text{cm}$     $\varnothing 10,5 \times H.47,2\text{''}$   
 $\varnothing 26,7 \times H.65\text{cm}$     $\varnothing 10,5 \times H.25\text{''}$

CE

ENNIE

## GENERAL SAFETY INSTRUCTIONS

- Please refer to the user manual for details on use and cleaning.
- In case of any danger, cut off the power supply and seek help from qualified personnel.
- Follow the warning signs and instructions.
- Do not use the product or its components for purposes other than intended.
- The company is not responsible for any problems that may arise from ceiling-mounted lighting installations carried out by anyone other than the Enne installation team.
- Do not interfere with the electrical or electronic components inside the product.
- Do not add or remove any components.
- Clean the surface using a damp cotton cloth.
- Do not use any chemical cleaners during cleaning.
- Do not allow the damp cloth used in cleaning to come into contact with electrical components.
- Position the cables of the movable or surface-mounted lights in a way that protects them from external damage.

## TRANSPORTATION INFORMATION

- The lighting products should be packaged and transported in an isolated and protected manner to prevent damage.
- For lighting products containing delicate components, the parts should be packaged separately, and the transport should be carried out by two people.
- They should not be stacked or stored together with chemical substances.
- They should not be transported together with liquid materials.
- If the lighting products are to be shipped abroad, they should be transported in crates.

## INSTALLATION AND ASSEMBLY

- Isolate the area.
- Cut off the power supply.
- If the product has accumulated dust due to waiting, ensure it is cleaned before starting installation.
- After unpacking the product, first mount the suspension bracket.
- After making the electrical connection, assemble the appropriate modules.
- Connect the accessories of the product.
- Do not turn on the power supply until the installation and assembly are fully completed.

## USER INSTRUCTIONS

- Do not interfere with the electrical or electronic components inside the product.
- Do not add or remove any components.
- Position the cables of the movable or surface-mounted lights in a way that protects them from external damage.

## CLEANING

- Clean the surface using a damp cotton cloth.
- Do not use any chemical cleaners during cleaning.
- Do not allow the damp cloth used in cleaning to come into contact with electrical components.



EUROPEAN CONFORMITY MARK



DO NOT OPERATE THE PRODUCT WITHOUT  
READING THE USER MANUAL



WARNING! HAZARD ALERT



INFORMATION



PROTECTIVE EARTH CONNECTION



HIGH VOLTAGE HAZARD



ALTERNATING CURRENT SUPPLY



DO NOT DISPOSE OF ELECTRONIC WASTE IN  
REGULAR TRASH



Made in Türkiye

## WARRANTY TERMS

- The warranty period begins on the delivery date of the lighting product.
- The entire lighting product, including all its components, is covered under our company's warranty.
- In the event of a malfunction during the warranty period, the time taken for repairs is added to the warranty period. The repair period is 20 business days. (For products arriving from abroad, it is 30 business days excluding shipping time.) This period starts from the date the defective product is delivered to the company.
- If the lighting product malfunctions due to material, workmanship, or installation defects within the warranty period, repairs will be carried out free of charge — including labor, replacement part costs, or any other fees. (Assuming the installation is carried out by Enne-authorized personnel.)
- Malfunctions resulting from usage that contradicts the instructions provided in the user manual are not covered under the warranty.
- Any interventions (such as repair or part replacement) made by anyone other than Enne-authorized personnel will void the warranty.

## APPLIED EU DIRECTIVE AND STANDARDS



2014/35/EU Low Voltage Directive

### STANDARDS:

- EN IEC 60598-1:2024  
Luminaires - Part 1: General requirements and tests
- EN IEC 60598-2-1:2021  
Luminaires - Part 2-1: Particular requirements - General purpose, fixed
- EN IEC 62031:2020  
LED modules for general lighting - Safety specifications
- EN 62717:2017  
LED modules for general lighting - Performance requirements

EN IEC 60598-1, EN IEC 60598-2-1, EN IEC 62031, EN 62717

## TECHNICAL DRAWING AND DETAILS



The operating voltage used in the transformers is in the range of 110–230 V.